

# MOSO LED Driver

Programming software

Use Instruction

# Content

<b>CHAPTER I Software Operating Environment .....</b>	<b>3</b>
1. Software operating environment.....	3
2. Install USB dongle (Programmer) drivers .....	3
3. Software operating instructions .....	4
<b>CHAPTER II Program instructions .....</b>	<b>5</b>
1. Connect to LED driver .....	5
2. Read LED driver parameters.....	6
3. Set LED driver current.....	7
4. Select dimming mode .....	7
5. Function button description .....	8
6. Set signal dimming .....	9
6.1 Set the Cut-off function.....	9
6.2 Set the dimming voltage.....	9
6.3 Set up reverse dimming .....	10
6.4 Soft-start function (For X7P series only).....	10
7. Setting the timer dimming.....	11
7.1 Traditional timing.....	11
7.2 Self Adapting-Percent .....	12
7.3 Self Adapting-Midnight .....	13
8. Set CLO.....	14
9. Read data record.....	14

## CHAPTER I Software Operating Environment

### 1. Software operating environment

#### 1.1 Hardware environment

CPU: 2GHz and above (32-bit or more)

RAM: 2GB and above

HD: 20GB and above


I/O: mouse, keyboard

#### 1.2 Software environment

Operating system: Windows XP, Win7, Win10 or above.

Component: Microsoft.NET Framework 4.0 or above version.

### 2. Install USB dongle (Programmer) drivers



名称	日期	类型	大小	标记
USB Dongle Driver	2024/2/27 15:23	文件夹		
LED_programming_UTILITY.exe	2024/1/11 14:39	应用程序	3,673 KB	
MOSO_H.bmp	2022/4/12 16:57	BMP 文件	29 KB	
wrie_0003.ico	2022/4/12 16:57	ICO 文件	67 KB	

Figure 1: The list of applications

The MOSO LED Driver programming software includes the above files, in which the USB Dongle Driver folder is the programmer driver software package. Open Driver folder, Shown as following figure:



Name	Date modified	Type	Size
CDM20824_Setup (XP).exe	2018-11-21 17:16	Application	1,703 KB
CDM21228_Setup.exe	2017-09-19 17:04	Application	2,393 KB

Figure 2: driver files

Install CDM20824\_Setup (driver for Windows XP) .exe on Windows XP system and CDM21228\_Setup (driver for Win7 Win10).exe on Win7 and above.

The driver file needs to be selected according to the number of operating system bits (32-bit or 64-bit).

The reference method is as follows:



## 3. Software operating instructions

名称	日期	类型	大小	标记
USB Dongle Driver	2024/2/27 15:23	文件夹		
LED_programming_UTILITY.exe	2024/1/11 14:39	应用程序	3,673 KB	
MOSO_H.bmp	2022/4/12 16:57	BMP 文件	29 KB	
wrie_0003.ico	2022/4/12 16:57	ICO 文件	67 KB	

Figure 3: The list of applications

Double click shortcut icon  to start software.

## CHAPTER II Program instructions

### 1. Connect to LED driver

First insert the "MS-PRG-W1" programmer into the USB port of the computer, and connect the other end to the LED driver Dim line. Open the "LED\_programming\_UTILITY" software and click "Connect" to connect the software to the LED driver, as shown in the figure below.




Figure 1: Connect to LED driver

If the connection is successful, the prompt "Connected" will be displayed at the top of the interface. If the power supply has been configured with a model before, it will automatically switch to the corresponding model, otherwise it will be the default model (User-defined).

At the same time, the U-I curve of the corresponding model is displayed on the left. The curve display allows the working area (gray dotted box), programming working area (blue area), constant power curve (red dotted line), output voltage range ( $V_{min} \sim V_{max}$ ), full power voltage range and other information. The programming work area changes according to the set current.

## 2. Read LED driver parameters

Click “Read” to read the power parameter. This function can check the power parameter configuration. Readable parameters include:

- 1) Set the current and dimming modes;
- 2) Whether to turn off, dimming voltage, and whether to reverse logic dimming;
- 3) Time-controlled dimming parameters;
- 4) CLO parameters.




Figure2: Read parameters

## 3. Set LED driver current

The output current of the power supply can be set according to actual needs. As shown below. When different currents are configured, the U-I curve programming work area changes according to the set current change.




Figure3: Set current

## 4. Select dimming mode

This software supports two optional dimming modes: "Signal Dimming" and "Timer Dimming".

Signal dimming includes "0-10V", "0-5V", "0-9V", "0-3.3V" analog voltage dimming and corresponding voltage PWM dimming.



Figure 4

## 5. Function button description




Figure 5

Read: read driver configuration parameters and display to the UI;

Default: restore the UI parameters to the factory default values;

Import: import the saved parameter values from a file and display them on the UI;

Save: save the interface display parameter values to a file;

Programming: write the configured parameters to the driver;

Download to offline programmer: Write the configured driver parameters to the offline programmer.

Note: The offline programmer is a programming tool kit developed by MOSO that can complete driver programming without relying on a computer. The kit is easy to use and quick to program. For detailed information about this product, please consult sales staff.

## 6. Set signal dimming

Select the "Signal Dimming" page to set related parameters.

### 6.1 Set the Cut-off function

If want to enable the cut-off function, check "Cut-off Setup" and "Cut-off ". If want to disable the cut-off function, uncheck "Cut-off Setup" and "Cut-off ".




Figure 6.1

### 6.2 Set the dimming voltage

4 types of dimming voltage can be selected: 0-10V, 0-5V, 0-9V, 0-3.3V. It can be selected according to the actual dimmer output voltage matching situation.




Figure 6.2

## 6.3 Set up reverse dimming

Reverse dimming: reverse logic dimming. The larger the input voltage of the dimming light, the smaller the output current of the power supply, and the smaller the input voltage of the dimming light, the larger the output current of the power supply. When you need to turn on the reverse dimming function, check "Set reverse dimming" and "Enable Reverse dimming". Uncheck "Enable reverse dimming" means forward dimming.




Figure 6.3.1

Signal Line maximum voltage output: When "Signal Line Max Voltage" is selected, the output voltage will be generated inside the dimming. 0-10V and 0-9V are about 10-12V, 0-5V and 0- 5V or so when 3.3V dimming.




Figure 6.3.2

## 6.4 Soft-start function (For X7P series only)

The Soft-start function is disabled by default. Select "EN\_SoftStart" and set the parameters to enable it (Default 3s or dimming 20%).




Figure 6.4

## 7. Setting the timer dimming

After selecting “Timer Dimming”, you can set the timing dimming related parameters. This software supports three timing dimming settings.

### 7.1 Traditional timing

After the power supply is powered on, it works according to the set “work step” time and output power. In this mode, the number of steps, step time and output power are always the same. When in use, configure the steps in the blue box as shown below.




Figure 7.1

## 7.2 Self Adapting-Percent

Check "Self Adapting-Percent" and select the reference days.




Figure 7.2

This function is to adapt to the case that the night time also changes with the season, and the time length parameter of the timing dimming also changes accordingly. To use this function, you need to set the parameters in "Set time" first. The software will calculate the night time of today tonight according to the night time (reference days) of the previous days. Assuming "reference days" is set to 7 days, the average of the night time for the first 7 days is taken as the night time for tonight. Then automatically adjust (according to the proportion of steps) the working time of each step (except step 0) according to the night time of this evening.

Example: Assume that the parameters of each step are: Step 1 is 2 hours and 30 minutes and the power is 100%; Step 2 is 3 hours and 30 minutes and the power is 80%; Step 3 is 2 hours and 0 minutes and the power is 50%. The total length of the three steps is 8 hours. According to the average of the night time in the previous 7 days, the night time is 10 hours. Then the duration of step 1 will be automatically adjusted to  $(2 \text{ hours and } 30 \text{ minutes}) \times 10 \div 8 = 150 \text{ minutes} \times 10 \div 8 = 3 \text{ hours and } 7.5 \text{ minutes}$ ; similar to this calculation, the duration of step 2 will be automatically adjusted to 4 hours 22.5 minutes, the duration of step 3 is automatically adjusted to 2 hours and 30 minutes. The initial night time is the traditional timed programming time.

## 7.3 Self Adapting-Midnight

Check "Self Adapting-Midnight" and set the reference days, midpoint, and initial time.




Figure 7.3.1

Self Adapting-Midnight: According to the estimated lighting tie, the curve lights are extended from the midpoint to the left and right respectively.

"Reference days": Same as "Self Adapting-Percent", the night time of the previous few days.

"Midnight" is the aligned time point, with a red vertical line.

"Initial time (duration)" is the preset lighting duration, and the red horizontal line in the time axis.

"Actual time (duration)": The estimated lighting duration based on the reference days, the blue horizontal line in the time axis.

After the LED driver is turned on, it works according to the adaptive (actual time) step and time and output power. The area step curve shown in yellow in the figure below.




Figure 7.3.2

Note: Unlike the other two timing modes, the midpoint alignment steps use relative time settings. The start time of step1 is 15:00, and the other steps are arranged in order.

## 8. Set CLO

Select "Enabled", configure the working time and the corresponding compensation current percentage, and click "Programming".



Figure 8

The compensation current percentage is the set current percentage. The maximum compensation percentage changes according to the change of the set current, and the maximum cannot exceed 20% of the set current.

Output voltage: Allowable working voltage range after compensating current.

Output power: The output power range within the allowable working voltage range under the current setting current. The maximum value is the power after compensating the current.

## 9. Read data record

Click "Read" to read the driver work log.




Figure 9

Driver work log, including:

The current temperature, the historical maximum temperature, the last maximum temperature, the current maximum temperature, and the total operating time of the driver.

You can also check the driver firmware version.

Current temp: Current drive temperature.

Historical T\_ Max: The highest temperature recorded in history.

Previous time T\_ Max: Record the highest temperature during the previous use.

This time T\_ Max: Record the highest temperature during this use.

Total working time: Record the total working time.

Firmware Ver.: Driver firmware version.